



VIEW SHOWN FOR ALL MODELS EXCEPT 59 & 71  
(FOR MODELS 59 & 71, SEE SHEET-2)

VIEW-A




VIEW-C




VIEW-D

FOR ROUTING OF 18A900 ASSY.  
ON MODELS WITH REAR SEAT RISER  
SEE VIEW-E



VIEW-B



ROUTING OF 18A900 ASSY. ON  
MODELS WITH REAR SEAT RISER

VIEW-E

COAF-18875-B KIT - RADIO REAR SEAT SPEAKER CONSISTS OF:		
PART NUMBER	PART NAME	REQD.
COAF-18A900-A	WIRING ASSY. - RADIO RECEIVER TO REAR SEAT SPEAKER	1
COAF-1897B-AW	GRILLE ASSY. - RADIO REAR SEAT SPEAKER	1
COAF-18821-AW	SCREEN ASSY. - REAR SEAT SPEAKER	1
372036-57	NUT - #8-32 WING	4
COAF-18971-A	SPEAKER ASSY. - RADIO REAR SEAT	1
COAF-19015-A	GASKET - RADIO REAR SEAT SPEAKER	1
IS.406	INSTALLATION SHEET (3-SHEETS)	1

I. S. 406  
INSTALLATION KIT  
RADIO REAR SEAT SPEAKER  
(SHEET 1 OF 3)

